

BSCK24

Hose Repair Kit for 3/16" & 1/4" I.D. Hose

Instructions: Insert hose with ferrule and splicer or nut and nipple in crimping tool. Offset tool approximately 1/8" from end of ferrule and apply pressure. Make 1/4 turn and apply pressure again.

Kit Contents: Also contains BSC5 Crimping Tool.



<p>30 (2pc)</p> <p>B to B Hose Coupler RH</p>	<p>31 (2pc)</p> <p>B to B Hose Coupler LH</p>	<p>K-K (8pc)</p> <p>Hose Ferrule</p>	<p>626 (6pc)</p> <p>Hose Ferrule</p>	<p>4750 (6pc)</p> <p>Hose Ferrule</p>	<p>769 (8pc)</p> <p>Hose Ferrule</p>
<p>7 (6pc)</p> <p>B size nut, RH</p>	<p>8 (6pc)</p> <p>B size nut, LH</p>	<p>18 (6pc)</p> <p>B size nipple, 3/16" barb</p>	<p>17 (6pc)</p> <p>B size nipple, 1/4" barb</p>	<p>45 (4pc)</p> <p>Hose Splicer 3/16"</p>	<p>44 (4pc)</p> <p>Hose Splicer 1/4"</p>