



AGHEADGEAR2.0

Armour Guard 2.0 Headgear (for all 2.0, SugarScoop & LionHood welding helmets)

Features

- Armour Guard replacement ratcheting type headgear, replacement headgear for all Amour Guard 2.0, Sugarcoop & Lion welding helmets
- Snap fastener for additional support and mobility
- Two side control knobs on outside of helmet for comfort control
- Popular welding helmet accessory, with adjustable features
- · Improved design for quicker replacement
- · Cushioned sleeve for additional comfort while welding

Technical Specifications

• Color: Black

Toll Free: (800) 445-2152

- Weight: .25 lbs. (4 oz.)
- Adjustable: Yes
- Compatibility: All Amour Guard 2.0, SugarScoop/LionHood Helmets
- Packaging: Individually packed
- Replacement dials, knobs, & spacers: AGHEADGEAR2.0DIALS


Fax: (404) 699-7800

sales@twusa.com



TECHNIWELDUSA

ARMOUR GUARD



AGHEADGEAR2.0 PARTS LIST

ITEM	DESCRIPTION	QTY
1	Sweatband	1
2	Headband	1
3	Screw	2
4	Limitation Washer	2
5	Left Adjustable Washer	1
6	Right Adjustable Washer	1
7	Rubber Spacer Ring	2
8	Left Angle Adjustable Washer	1
9	Right Angle Adjustable Washer	1
10	Washer	2
11	Headband Adjustable Nut	2

HOW TO ATTACH AGHEADGEAR2.0 TO A WELDING HELMET





1. Remove Washer & Headband Adjusting Nut from headgear



2. Insert screw in helmet slot aligning square peg to square notch



3. Place washer around screw



4. Attach Headband Adjusting Nut to screw

5. Repeat Steps 1-4 for other side of the welding helmet